



# WaterWall

Dimensions			Pieces Needed		
Width	Depth	Height	Small (4 x 4 x 8)	Medium (8 x 4 x 8)	Large (8 x 4 x 12)
56"	40"	34"	3	31	48

## Additional Items Needed

**Glue:** 3 (10.5 oz tubes)

**Tools Needed:** Level, Caulking Gun

## Instructions:

### 1. Prepare a stable, level project area by following these steps:

- Excavate area approximately 5" below grade
- Excavate approximately 6" larger than the actual project dimensions
- Fill 4" with suitable base material, compact and level in all directions

**If installing on an existing patio or suitable base you may proceed to install the project after ensuring the base is level.**

**2. We recommend not gluing the project until it has been assembled completely, including the WaterWall kit.** Then, once everything fits, downstack a few layers and glue just a few of the upper layers. For maintenance, do not ever glue the middle wall cap on the last layer. This will give you access to adjust and maintain the weir.



**3. These instructions are designed for the Aquascape WaterWall Spillway Kit (item code 58080).** An internet search will come up with several sources to purchase from."

**4. Follow the manufacturer's installation instructions except we recommend waiting to glue the pvc tubing until after everything has been installed and "dry fitted" together.** We further recommend waiting until the metal weir has been placed to determine the appropriate length of tubing to cut between the weir and the tank."





## Water Wall

