



## SEK Efflo-Off Slab Installation Cleaning Specification

*Always test product on a small area (or sample slab) first and allow 24-hour dry-time to determine ease of application and desired results.*

1. Lightly pre-wet (flash-cool) the slab surface (do not soak). If plant material is nearby, protect and/or keep wet during detergent application.
2. Pre-mix **Efflo-Off** at a ratio of 4-parts water: 1-part detergent.
3. Apply **Efflo-Off** (diluted to 4:1 ratio) to the pavement surface to be cleaned. You can do this with a 1-gallon or 2-gallon plastic pump sprayer. Ensure to overlap each spray stroke to achieve full even coverage.
4. Allow product to dwell for 5 to 8 minutes, being careful to not allow the product to dry on the pavement surface. If liquid begins to dry on surface, then re-apply to keep surface wet.
5. While the detergent is dwelling on the pavement, lightly agitate the detergent on the pavement surface with a push broom.
6. Do not rinse.
7. Once again, apply **Efflo-Off** (diluted to 4:1 ratio) to the pavement surface. Allow product to dwell again for 2 to 4 minutes. This melts any remaining residue/efflorescence.
8. Rinse with garden hose-end sprayer. Use long even strokes that overlap each other.
9. Allow pavement to dry for 24 hours then inspect treatment. Repeat steps 1-8, as necessary, to achieve desired result.

For more detailed information, consult... <http://sek.us.com/products/surebond-cleaners/efflo-off/>

It is always recommended to pre-test each product for each application. There can be so many variables from job to job, that even what may have worked in the past could change slightly. For new construction, a mock up panel is always best to clean prior to full scale cleaning. This will give everyone the opportunity to see the end-results before the project begins.

<http://sek.us.com/products/surebond-cleaners/efflo-off/>